Zeiss Upright Switch On/Off Procedures

- 1. Switch on microscope (wall plug labelled Microscope)
- 2. Switch on camera (wall plug labelled Camera)
- 3. Log in
- 4. Run Micro-Manager program (configure file (*.cfg) is in C:\temp)

Need help? Contact Yan Gu: 07981875417, office: 2c37, ext:6997

- 1. Close Micro-Manager program
- 2. Log off
- 3. Switch off camera (wall plug labelled Camera)
- 4. Switch off microscope (wall plug labelled Microscope)
- 5. Clean the objective (Only when use immersion oil, with lens tissue)
- 6. Sign off log book