

















6.Operation

6.1 Main Menu



	POWER: Turn the visual presenter on / off		LAMP: Turn the lamp on / off
	AUTO TUNE: Automatically adjust the image for best possible quality.		PREVIEW: Display live images
	OPTIONS: Select video compression method and the audio source.		BRIGHTNESS: Adjust image brightness
	MAIN: Launch the main functions menu Right click on this icon to show information about the Ladibug™.		ZOOM: Zoom in/out from the image
	CAMERA SETTING: Launch the Camera Setting window to adjust live images		ADVANCE: Launch the advanced functions menu
	FREEZE: Freeze a live image		ANNOTATION: Display annotation tools
	CLOSE: Close the Ladibug™.		TIME LAPSE PHOTOGRAPHY: Capture images at a pre-set intervals
	RECORD: Record videos		CAPTURE: Capture still images